

FireCracker RF Computer Interface/Transceiver

Model CM19A

INSTALLATION INSTRUCTIONS

The CM19A Computer Interface sends and receives Wireless Radio Frequency (RF) signals, and works with X10's MultiView or X-Ray Vision software. It receives RF commands from X10 motion detectors (sold separately) and communicates these commands to the MultiView or X-Ray Vision software. The software interprets these commands and tells a CM19A to transmit the appropriate RF commands to a TM751 Transceiver (sold separately). The CM19A can therefore work with the MultiView or X-Ray Vision software to automatically turn on lights, appliances, and cameras when X10 motion detectors are tripped.

IMPORTANT: Use of the CM19A requires Windows® 95 OSR 2.1 with USB support, or Windows 98.

DO NOT plug the CM19A into your PC until you install the X10 software.

1. Download the desired software application from:
www.x10.com/software
2. Install the software following the instructions that came with it.
3. When instructed during the installation process plug the CM19A into any unused USB port.
4. Windows will recognize the CM19A and complete the installation. Refer to the application's help file for additional information.

For more information, please visit:

www.x10.com/support

® Windows is a Registered Trademark of Microsoft Corporation.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

X10 Wireless Technology, Inc. LIMITED 1-YEAR WARRANTY

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 agrees to repair or replace, at its sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Call 1-800-675-3044 or visit www.x10.com, or e-mail sales@x10.com to obtain a Return Merchandise Authorization (RMA) number.
2. Return the defective unit postage prepaid to X10 (see address on back).
3. Enclose a check for \$4.00 to cover postage and handling.
4. Enclose a dated proof of purchase.
5. X10 is not responsible for shipping damage. Units to be returned should be packed carefully.

Please visit www.x10.com/warranty to complete your on-line warranty registration. Thank you.